

DESIGN ENVELOPE 4380, 4372, 4300, 4322 PUMPS BLANKING KIT | SERVICE WORK INSTRUCTIONS

File No: 100.815
Date: NOVEMBER 09, 2017
Supersedes: NEW
Date: NEW

Refer to appropriate service work instructions (swi) file for breakdown instruction for the pump being serviced. Seal replacement instructions are included in the pump swi. The following instructions are included for convenience.

CAUTION



Always disconnect power supply from motor before beginning service work.

SEAL KIT INSTALLATION INSTRUCTIONS

- 1 Disconnect power.
- 2 The service must be completed by an authorized person approved by Armstrong. Call the phone numbers below for service.
- 3 Pump Manager must be updated by the authorized service person.

TORONTO

+1 416 755 2291

BUFFALO

+1 716 693 8813

BIRMINGHAM

+44 (0) 8444 145 145

MANCHESTER

+44 (0) 8444 145 145

BANGALORE

+91 (0) 80 4906 3555

SHANGHAI

+86 (0) 21 5237 0909

SÃO PAULO

+55 11 4781 5500