

BLADDER TANKS | REPLACEMENT INSTRUCTIONS

File No: 37.78


Date: DECEMBER 17, 2015

Supersedes: NEW

Date: NEW

BLADDER TANKS 60 TO 2000 LITERS

- 1 Tank must be drained and all pressure released.
- Bladder is attached to tank at both ends. To release bladder remove steel cap, locknut & washer, and the disc from top fitting. This fitting can now be pushed down inside the tank and bladder. To release bladder from opposite end, remove all nuts from flange and then take off cover plate.
- 3 You will now be able to reach in and remove bladder.
- **4** To install new bladder, insert top assembly into bladder and then carefully position new bladder into tank so that top assembly nipple protrudes through hole in top of tank.
- 5 Install disc, locknut & washer, and steel cap to a snug fit.
- **6** To complete bladder attachment, you will note that the bladder has a gasket molded right with the bag. Make sure the bladder is not twisted on the interior of the tank.
- **7** Re-attach cover plate to make an air and watertight seal.
- 8 Re-charge tank to 2 PSI under low system pressure.
- **9** Apply a soapy water solution to check for air leaks.



TORONTO

23 BERTRAND AVENUE TORONTO, ONTARIO CANADA M1L 2P3 +1 416 755 2291

BUFFALO

93 EAST AVENUE NORTH TONAWANDA, NEW YORK U.S.A. 14120-6594 +1 716 693 8813

BIRMINGHAM

HEYWOOD WHARF, MUCKLOW HILL HALESOWEN, WEST MIDLANDS UNITED KINGDOM B62 8DJ +44 (0) 8444 145 145

MANCHESTER

WOLVERTON STREET
MANCHESTER
UNITED KINGDOM
M11 2ET
+44 (0) 8444 145 145

BANGALORE

#59, FIRST FLOOR, 3RD MAIN MARGOSA ROAD, MALLESWARAM BANGALORE, INDIA 560 003 +91 (0) 80 4906 3555

SHANGHAI

NO. 1619 HU HANG ROAD, XI DU TOWNSHIP FENG XIAN DISTRICT, SHANGHAI P.R.C. 201401 +86 21 3756 6696

SÃO PAULO

RUA JOSÉ SEMIÃO RODRIGUES AGOSTINHO, 1370 GALPÃO 6 EMBU DAS ARTES SAO PAULO, BRAZIL +55 11 4781 5500

ARMSTRONG FLUID TECHNOLOGY ESTABLISHED 1934

ARMSTRONGFLUIDTECHNOLOGY.COM

