

SINGLE PHASE SIMPLEX MODEL 112


FILE NO.: 53.534 DATE: Feb. 15, 2001 SUPERSEDES: NEW

SUBMITTAL

Job:	Representative:	
Engineer:Contractor:	Order By:Submitted By:Approved By:	Date:

Single phase, simplex motor contactor control.

The Model 112 control panel provides a reliable means of controlling one 120, or 240 VAC single-phase pump in pump chambers, sump pump basins, irrigation systems and lift stations. Two control switches activate a magnetic motor contactor to turn the pump on and off. If an alarm condition occurs, an additional alarm switch activates the audio/visual alarm system.



- Enclosure measures 8 x 8 x 4 inches (20.32 X 20.32 X 10.16 cm). NEMA 4X (ultraviolet stabilized thermoplastic with removable flanges for outdoor or indoor use).
 - ★ Options selected may increase enclosure size and change component layout.
- 2. Magnetic Motor Contactor controls pump by switching hot electrical lines.
- 3. HOA Switch for manual pump control (mounted on circuit board).
- 4. Green Pump Run Indicator Light (mounted on circuit board).
- 5. Float Switch Terminal Block (mounted on circuit board).
- 6. Alarm and Control Fuses (mounted on circuit board).
- 7. Alarm and Control Power Indicators (mounted on circuit board).
- 8. Pump Input Power and Pump Connection Terminal Block
- 9. Ground Lug
- 10. Terminal Block Installation Label
- 11. Circuit Breaker provides pump disconnect and branch circuit protection.

STANDARD ALARM PACKAGE

- 12. Red Alarm Beacon provides 360° visual check of alarm condition.
- **13. Alarm Horn** provides audio warning of alarm condition (83 to 85 decibel rating).
- **14.** Exterior Horn Test/Normal/Silence Switch allows alarm horn to be silenced and testing of horn and light to ensure proper operation of alarm system.
- **15.** Horn Silence Relay automatically resets alarm after alarm condition has been resolved (mounted on circuit board).



indoor/outdoor

FEATURES


- Entire control system (panel and switches) is UL Listed to meet and/or exceed industry safety standards
- Dual safety certification for the United States and Canada
- Complete with step-by-step installation instructions
- Three-year limited warranty
- Auxiliary alarm contact, form C type
- Door mounted pump run indicator



OPTIONS

★ 4A	Alarm flasher Low level cutout - requires float. Red low-level indicator & alarm
l	must select 4A
★ 8A	Elapsed time meter
★ 8C	Event (cycle) counter
10E	Lockable latch - NEMA 4X
★10F	Lightning arrester
<u></u> ★10K	Anti-condensation heater
15A	Control / alarm circuit breaker
	Does not include the circuit boar
	as in standard.

SINGLE PHASE - SIMPLEX MODEL 112



S.A. Armstrong Limited 23 Bertrand Avenue Toronto, Ontario Canada, M1L 2P3 Tel: (416) 755-2291 Fax: (416) 759-9101 Visit us at www.armstrongpumps.com Armstrong Pumps Limited Peartree Road, Stanway Colchester, Essex United Kingdom, C03 5JX Tel: 01206-579491 Fax: 01206-760532



Armstrong Pumps Inc. 93 East Avenue Buffalo, New York U.S.A. 14120-6594 Tel: (716) 693-8813

U.S.A. 14120-6594 Canada, H9P
Tel: (716) 693-8813 Tel: (514) 421-2
Fax: (716) 693-8970 Fax: (514) 421-2

© S.A. Armstrong Limited 2000

Armstrong Darling Inc.

2200 Place Transcanadienne Montreal, Quebec Canada, H9P 2X5 Tel: (514) 421-2424 Fax: (514) 421-2436

