



# GRINDER START CAPACITOR BOX

FILE NO.:	53.549
DATE:	Feb. 15, 2001
SUPERSEDES:	NEW

## SUBMITTAL

Job: _____	Representative: _____
_____	_____
_____	Order By: _____ Date: _____
Engineer: _____	Submitted By: _____ Date: _____
Contractor: _____	Approved By: _____ Date: _____

### SINGLE PHASE, GRINDER CAPACITOR START BOX.

Provides a means to start a single phase grinder pump. Start box contains start capacitor, start relay and terminal block for float connection.

Required for grinder pump operation.



#### FEATURES

- NEMA 4X enclosure rated for outdoor use.
- Terminal block for connection of pump and float.
- Hinged door.
- Three-year limited warranty.
- Start relay and start capacitor.

#### SPECIFICATIONS

**LID AND BOX:** UL Approved and CSA Certified made from high impact, corrosion resistant, weatherproof thermoplastic


**GASKET:** flexible foam

**PART NO.:** 174026-003

**EXTERNAL ENCLOSURE SIZE:**

- 6.5x10x3.75 inches  
(16.25 x 25 x 9.38 cm)

# SINGLE PHASE GRINDER CAPACITOR START BOX



**S.A. Armstrong Limited**  
23 Bertrand Avenue  
Toronto, Ontario  
Canada, M1L 2P3  
Tel: (416) 755-2291  
Fax: (416) 759-9101  
Visit us at [www.armstrongpumps.com](http://www.armstrongpumps.com)

**Armstrong Pumps Limited**  
Peartree Road, Stanway  
Colchester, Essex  
United Kingdom, C03 5JX  
Tel: 01206-579491  
Fax: 01206-760532



**Armstrong Pumps Inc.**  
93 East Avenue  
Buffalo, New York  
U.S.A. 14120-6594  
Tel: (716) 693-8813  
Fax: (716) 693-8970

**Armstrong Darling Inc.**  
2200 Place Transcanadienne  
Montreal, Quebec  
Canada, H9P 2X5  
Tel: (514) 421-2424  
Fax: (514) 421-2436

© S.A. Armstrong Limited 2000

