



## DISCHARGE HEAD ACCESSORIES


### HEAD SHAFT ASSEMBLY




### COLUMN ADJUSTMENT ASSEMBLY




### OIL LUBE AND TENSION ASSEMBLY



### PRODUCT LUBE PACKING BOX ASSEMBLY



### MECHANICAL SEAL ASSEMBLY



**S.A. Armstrong Limited**  
 23 Bertrand Avenue  
 Toronto, Ontario  
 Canada, M1L 2P3  
 Tel: (416) 755-2291  
 Fax: (416) 759-9101

**Armstrong Pumps Limited**  
 Peartree Road, Stanway  
 Colchester, Essex  
 United Kingdom, C03 5JX  
 Tel: 01206-579491  
 Fax: 01206-760532



**Armstrong Pumps Inc.**  
 93 East Avenue  
 Buffalo, New York  
 U.S.A. 14120-6594  
 Tel: (716) 693-8813  
 Fax: (716) 693-8970  
 1-800-FLOW-845

**Armstrong Darling Inc.**  
 2200 Place Transcanadienne  
 Montreal, Quebec  
 Canada, H9P 2X5  
 Tel: (514) 421-2424  
 Fax: (514) 421-2436  
 Printed in Canada